



genpa.com.tr

MAGSAFE ŞARJ ARAÇ TUTUCU MAGS18K KULLANIM KALAVUZU

MENŞEİ VE İTHALAT BELGESİ CEP TELEFONU AKSESUARİ

Üretim Yeri: Çin

İthalatçı Firma: ER-TEL Erdem Telekomünikasyon
Elektronik ve Bilgi İşlem San. Tic. A.Ş.
Nispetiye Cad. No:101 Etiler 34337 Beşiktaş/İstanbul
Tel:0212 359 00 00 Fax: 0212 287 39 39



MAGSAFE ARAÇ ŞARJ ALETİ Kullanım Klavuzu



Bu ürünü satın aldığınız ve kullandığınız için teşekkür ederiz!

Lütfen bu ürünü kullanmadan önce bu kullanım talimatını dikkatlice okuyun.

Ürün Özellikleri

MAGSAFE ARAÇ ŞARJ ALETİ


-Giriş: 5V=2A/9V=2A

-Çıkış: 5W/7.5W/10W/15W

-Şarj Verimliliği: %80

Uyumlu Cihazlar

Magsafe uyumlu iPhone telefonlar



MADE IN CHINA

⚠ Kablosuz şarj sırasında LED ışığı kırmızıya dönerse, bu bir şarj hatasını gösterir.


Aşağıdaki durumlar, yavaş şarj, şarjın durması veya şarj konumunda aşırı sıcaklık gibi hatalara neden olabilir.

1. Adaptör standartlara uygun değil (PC USB çıkış güç kaynağı yok).
2. Şarj kablosu standartlara uygun değil.
3. Telefon kılıfı çok kalın (2 mm kalınlığında telefon kılıfı önerilir).
4. Dahili kablosuz şarj alıcısının konumu, kablosuz şarj cihazı bobini ile örtüşmüyor.
5. Cep telefonunun veya telefon kılıfının arkasında metal/mıknatıs var.
6. Akıllı telefon kablosuz şarj işlevini desteklemiyor.

⚠ Dikkat

1. Şarj cihazını sudan veya diğer sıvılardan uzak tutun.
2. Şarj cihazını temizlemeniz gerekiyorsa, güç kaynağına bağlı olmadığınızdan emin olun.
3. Çalışma sıcaklığı: -20-45°C.**

Ürün Tanımı




1. Semiconductor cooling technology makes the phone fully charged quickly in about 2.5 hours.
2. Use your driving time to charge your iPhone, eliminating low battery anxiety.

Havalandırma Montajı

1. Üç parçayı monte etmek için okları takip edin.




2. Vida kapağını en uygun konuma getirin.




3. Kancayı en uzun konuma getirmek için kasağı sola çevirin.



4. Kancaların hava menfezi kanatlarını sıkıştırması için kasağı sağa çevirin.




5. Montaj tamamlanmıştır



Kablosuz Şarj Aleti Çalışması

Input: Connect the wireless charger and car adapter with the charging cable.



Please use a PD/QC3.0 adapter so that the charging will enter the fast charging mode.

LED gösterge ışığı:

Beyaz LED Işığı: Bekleme.

Mavi LED Işığı: Normal şarj.

Kırmızı LED Işığı: Anormal şarj.

LED gösterge ışığı

Magsafe Kullanımı

Kılıfsız

Apple Magsafe Kılıfı

Farklı Magsafe Kılıfı

Kalın Kılıf

Normal Kılıf

Metalli Kılıf

MAGSAFE CAR CHARGER User Guide

Model: S18

Thank you for purchasing and using this product!

Please read this operation instruction carefully before using this product.

Product Specification

MagSafe Car Charger

• Input: 5V---2A/9V---2A

• Output: 5W/7.5W/10W/15W

• Charging Efficiency: 80%

Applicable Devices

Compatible with MagSafe iPhone.

MADE IN CHINA

⚠ The LED light turns red during wireless charging to indicate a charging failure.

The following situation can cause failures, like charging slowly, stop charging, over-temperature for charging position.

1. The adapter is not run up to standard (No PC USB output power supply).
2. The charging cable is not up to standard.
3. The phone case is too thick (within 2mm thickness phone case recommended).
4. The built-in wireless charging receiver position is not coincided with wireless charger coil position.
5. There is metal/magnet on the back of cell phone or phone case.
6. Smartphone does not support wireless charging function.

⚠ Attention

1. Please keep the charger away from water or other liquid.
2. If you need to clean the charger, please make sure it is not connected to power supply.
3. Operating temperature: -20-45°C.

Product Description

1. Semiconductor cooling technology makes the phone fully charged quickly in about 2.5 hours.
2. Use your driving time to charge your iPhone, eliminating low battery anxiety.

Step to install air vent

1. Follow the arrows to install 3 parts.

2. Adjust the screw cap to the best active status.

3. Turn the pulley to the left to adjust the hook to the longest.

4. Rotate the pulley to the right to make the hooks to clamp the air vent blades.

5. Installation completed.

Wireless Charger Operation

Input: Connect the wireless charger and car adapter with the charging cable.

Please use a PD/QC3.0 adapter so that the charging will enter the fast charging mode.

LED indicator light :

White LED Light: Standby.

Blue LED Light: Charging normally.

Red LED Light: Charging abnormally.

LED indicator light

MagSafe Usage

Non-case

Apple MagSafe case

Other MagSafe case

Thick case

Normal case

Metal

